

DETAIL #: AVM-0570-4001

AVM SYSTEM 570

PLAZA DECK

Deck to Wall Inside Corner Detail
AVM Aussie Membrane 570
Hot Rubber



AVM SYSTEM
570 30 MIL
TACK COAT

WALL

AVM 570
NEOPRENE
FLASHING

SETTING BED
FOR PAVERS

AVM SYSTEM
570 30 MIL
TACK COAT

WALL

PLAZA DECK

AVM 570
NEOPRENE
FLASHING

PLAZA DECK

STEP 1

APPLY TACK COAT
AND INSTALL FIRST
LAYER OF FLASHING
AS SHOWN

STEP 2

APPLY ANOTHER TACK
COAT AND INSTALL
SECOND LAYER OF
FLASHING AS SHOWN

WALL

PLAZA DECK

STEP 3

COMPLETELY COAT NEOPRENE FLASHING WITH AVM SYSTEM 570
IMMEDIATELY AFTER INSTALLATION

AVM Industries, Inc.
8245 Remmet Ave, Canoga Park, CA 91304

Quality Waterproofing Products

888.414.1041 818.888.0050
www.avmindustries.com

FILE NAME: 0570-4001-Deck-to-Wall-Inside-Corner-Detail
Protected by Copyright - AVM Industries, Inc.

Revision Date 1/23/2019