

DETAIL #: AVM-0570-4011

AVM SYSTEM 570

PLAZA DECK

Deck to Wall Outside Corner Detail
AVM Aussie Membrane 570
Hot Rubber



AVM SYSTEM 570 30 ML
TACK COAT

WALL

PLAZA DECK

AVM 570
NEOPRENE
FLASHING

WALL

AVM 570 NEOPRENE
FLASHING

PLAZA DECK

STEP 1

APPLY ADHESIVE AND
INSTALL FIRST LAYER OF
FLASHING AS SHOWN

AVM SYSTEM
570 30 ML TACK
COAT

WALL

STEP 2

APPLY ANOTHER TACK
COAT AND INSTALL
SECOND LAYER OF
FLASHING AS SHOWN

PLAZA DECK

STEP 3

COMPLETELY COAT NEOPRENE FLASHING WITH AVM SYSTEM
570 90 MIL BASE COAT IMMEDIATELY AFTER INSTALLATION