



INDUSTRIES, INC.

8245 Remmet Ave, Canoga Park, CA. 91304-4133
Tel: (888) 414-1041 Tel: (818) 888-0050 Fax: (818) 888-0030

Maintenance Instructions

AVM System 500, AUSSIE MEMBRANE

Congratulations on your selection of the AVM System 500, Aussie Membrane! The membrane you have chosen is a high quality waterproofing membrane that will provide years of protection and performance.

MAINTENANCE:

The best part is: **No periodical maintenance is required!**

PROTECTION

For best results, have the membrane covered with adequate protection once cured. Typical protection could be AVM Approved fan-fold foam board, foam or other hard surfaced panels, drainage boards, etc. Do NOT leave membrane exposed to UV for more than 14 days!

PERIODICAL INSPECTIONS:

AVM Recommends that the areas waterproofed with the Aussie Membrane be inspected twice each year. Areas might include retaining walls, planters, between-slab waterproofing, roof paver systems, roof gardens, etc.

Things to look for should include:

1. Inspect the protection materials (ie, Drain boards, protection boards, protective panels, etc) and make sure that they are intact, un-damaged and are still properly attached.
2. Inspect the exposed portions of the drainage boards when applicable to make sure that they are clear of debris and will drain water properly.
3. Inspect drains and overflows when applicable to make sure that they are properly attached, have the necessary protection screens and that they are clear of debris and will drain water properly.

REPAIRS TO THE MEMBRANE:

ACCIDENTAL DAMAGE / REMODELING, Etc: Contact AVM Industries, your Distributor or your local Authorized Applicator for assistance. Do not leave damage unattended. It could void the warranty.