



AVM Primer 570-WB

Zero-VOC, Water-Based Sprayable Primer for Aussie Membrane® 570 Hot Rubber

Sections 071000 / 071400 / 071413

Product Name

AVM Primer 570-WB

By

AVM Industries, Inc.
8245 Remmet Ave, Canoga Park, CA 91304
888.414.1041 818.888.0050
www.avmindustries.com

Product Description

AVM Primer 570-WB is a zero VOC, penetrating water-based primer that will promote adhesion of AVM's Aussie Membrane 570 to concrete substrates

Where to Use

Over concrete substrates.

Limitations

Keep product protected from freezing. Do not apply when rain is imminent.

Submittals

When applicable, submit this Technical Data Sheet along with the appropriate waterproofing system documentation.

Warranty

This product is used as a component of a waterproofing system. Refer to that system's warranty for details.

Delivery, Storage, and Handling

- Delivery of the **AVM Primer 570-WB** materials to the job site must be in their original sealed containers with manufacturer's name and label intact.
- Handle and store containers in accordance with printed instructions.
- Store indoors at temperatures between 40°F and 90°F. Do not store materials in direct sunlight or where they may be damaged by water or rain.
- Keep all materials out of the reach of children.
- Store in a well-ventilated place. Store locked up.
- If irritation occurs during use, liberally flush affected areas with water. If irritation continues, see a physician immediately.
- Shelf life: One year from date of manufacture when properly stored indoors.



Project Conditions

All surfaces to which the **AVM Primer 570-WB** is applied to must be sound, stable, dry, with an even finish and free from dust, loose debris, grease, curing agents, etc. Refer to AVM Hot Rubber 570 Installation Instructions for additional substrate and preparation information.

System Application

Read the AVM Hot Rubber 570 Installation Instructions Prior to Installation.

- Ready to use - do not dilute
 - Water Based - use with adequate ventilation
 - Mix thoroughly before use.
- Apply materials in dry weather, when ambient temperatures are between 40°F and 100°F. Do not leave exposed to U.V. Cover with membrane as soon as possible.
 - AVM Primer 570-WB** can be applied on vertical and horizontal surfaces by lightly spraying the surface at a rate of 250-300 square feet per gallon, after the area has been prepped for installation of AVM's Aussie Membrane 570. Only Fog Spray Primer 570-WB. Do not apply with roller. Over-application may cause adhesion problems between the concrete and the Aussie Membrane 570. If more than 24 hours have gone by before Hot Rubber installation, re-prime.
 - The AVM Primer 570 must be allowed sufficient time to dry. Drying times may increase when temperatures are cooler or humidity is higher.
 - Warn personnel against hazards of materials to skin and eyes. Note other hazardous conditions on the job that might require special protective gear and or any other special protective or safety procedures.
 - Protect adjacent surfaces which could be damaged during the application procedure.

Quality Control

- Visually inspect all treated surfaces to ensure a full and proper coating application, especially at corners, drainage scuppers and hard-to-reach areas.
- All unsatisfactory areas shall be re-primed prior to waterproofing system application.

Protection of Installed Primer

Protect treated surfaces from dust, debris and unnecessary traffic until the AVM Hot Rubber 570 can be installed.

Clean Up

When dry, **AVM Primer 570-WB** can be cleaned from equipment using mineral spirits. Tools may be cleaned with soapy water before the material hardens.

Availability and Cost

Contact AVM Industries or your approved applicator for pricing and availability.

Technical Services

Technical services are available by contacting our offices at: **888.414.1041** or **818.888.0050** or visit www.avmindustries.com

System Specifications

See next page.

The following coverages are based on controlled tests. Actual coverages may vary.

General Data - AVM Primer 570-WB

Shelf Life: One year in original unopened packaging.

Dry Time: Dry to the touch time @ 72°F 60 minutes.

Storage: Store dry at 40°F - 90°F.

Item/Component	Packaging	Approx Shipping Weights	Qty per Pallet	Coverages	VOC
Primer 570-WB	5-Gal Buckets	41.0 lbs./Bucket - 1526 Lbs/Pallet	36 Buckets/Pallet	250-300 sqft/Gal	0 g/l

For a complete list of details in CAD or PDF, please visit our website at www.avmindustries.com.

AVM Industries, Inc.
8245 Remmet Ave, Canoga Park, CA 91304
888.414.1041 818.888.0050

Quality Waterproofing Products



www.avmindustries.com