Sections - 071000 / 071400 / 071416



# AVM Aussie Powder 500

For Trowel Grade Bituminous Membrane
For Fast Curing Bituminous Patch

Sections 071000 / 071400 / 071416 Fluid Applied Waterproofing

# Product Name AVM Aussie Powder 500

# Manufactured by

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.aymindustries.com

## **Product Description**

Aussie Powder 500 is a specialized proprietary additive (In Powder form) designed to enhance the versatility of Aussie Membrane 500. When combined with Aussie Membrane 500, it transforms the liquid membrane into a trowel-grade membrane suitable for thicker membrane applications or an even thicker bituminous patch suitable for patching and detailing.

**Aussie Powder 500** is fully compatible with, and provides seamless integration into the Aussie 500 Liquid Bitumen.

#### Where to Use

**Trowel Grade Membrane:** When adding 1 kg of **Aussie Powder** to a 5-Gallon bucket of Aussie Membrane 500, it makes the bitumen liquid thicker turning into a thicker Trowel Grade mastic.

Fast Curing Patch: When adding 2 kg of Aussie Powder to a 5-Gallon bucket of Aussie Membrane 500, it turns the bitumen into a Fast Curing Patch.

# **Features and Benefits**

**Compatibility:** Specifically designed to integrate with Aussie Membrane 500.

**Enhanced Performance:** Creates a smooth, trowelable consistency for targeted applications or a patch to be used as needed.

**User-Friendly:** Easy to mix and apply in the field.

**Proprietary Blend:** Maintains the integrity of the waterproofing system without compromising long-term performance

#### Warranty

For complete warranty details, contact AVM Industries or consult with your applicator.



### Delivery, Storage, and Handling

- Delivery of the Aussie Powder materials to the job site must be in their original sealed containers, with manufacturer's name and label intact
- b. Handle and store containers in accordance with printed instructions.
- c. Store at temperatures between 50°F and 90°F. Do not store materials in direct sunlight or where they may be damaged by water or rain. In tropical climates (where it is very hot and humid) the product must be stored in an air-conditioned environment. Do not allow product to freeze.
- Failure to comply with the recommended storage conditions may result in premature deterioration of the product. For specific storage advice, please contact AVM Industries and/or its representatives.
- e. Shelf Life 5 years from date of manufacture.
- f. Keep all materials out of the reach of children.
- g. If irritation occurs during use, liberally flush affected areas with water. If irritation continues, see a physician immediately.

# **Mixing Instructions**

Add **Aussie Powder 500** to the Aussie Membrane 500 based on the following guidelines:

- 1. **1-Gallon Membrane:** Add 2 scoops for a trowel grade (thicker membrane) and 4 scoops for a patch.
  - **5 Gallon Membrane:** Add 1 Jar (1 kg) for trowel grade (thicker membrane) and 2 Jars (2 Kg) for a patch.
- 2. Stir thoroughly until a smooth, consistent mixture is achieved.
- For Patch: Adjust the amount of powder as needed for desired consistency.
   For trowel grade: DO NOT exceed the recommended amount.

**Pot Life:** The pot life of the mixed product (Powder + liquid bitumen) may vary based on temperature, humidity and qty of powder used. Pot life could be as short as 15-20 minutes.

# **System Application**

See Aussie 500 Technical Data Sheet or Aussie 500 Installation Instructions.

# **Availability and Cost**

Contact AVM Industries or your approved applicator for pricing and availability.

#### **Technical Services**

Technical services are available by contacting our offices at: 888.414.1041 or 818.888.0050 or visit www.avmindustries.com

# **System Specifications**

See below.



# The following coverages are based on controlled tests. Actual coverages may vary.

Item / Component	Packaging	Approx Shipping Weights	voc
AVM Aussie Powder	Jar	1 kg (2.2 Pounds)	

# SUGGESTED MIXING INSTRUCTIONS

	For a Thicker Membrane: ADD	For Aussie Patch: ADD
1-Gal.	2 Scoops	4 Scoops
5-Gal.	1 Jar	2 Jars

The actual quantity of powder to be added may be adjusted as needed.

For a complete list of details in CAD or PDF, please visit our website at www.avmindustries.com.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050

**Quality Waterproofing Products** 

**NOTICE STATE**