


DETAIL #:
0570-7002
System:
AVM System 570

Planter to Wall Transition

AVM System 570



USE AVM ADHESIVE 570 ON CONCRETE RECEIVING AVM SYSTEM 570

- Notes:
- 1. Aussie System 520 may require Epoxy Primer