

<b>PROJECT NAME:</b>		
<b>DATE:</b>	<b>WEATHER:</b>	<b>REPORT#:</b>

HORIZONTAL INSTALLATION		YES	NO	N/A	NOTES
1	Concrete substrate is clean and dry				
2	Substrate sufficiently smooth, clean profile				
3	Cracks >3/16" routed and sealed with Aussie Seal M				
4	Cracks detailed with Mat 800 Reinforcement Fabric				
5	Plywood substrate joints detailed per AVM Detail -				
6	Concrete sloped to drain - min. 1/4" per foot				
7	Aussie Seal M fillet (3/4") at all inside corners				
8	For Aussie Membrane 500: Primed with AVM Adhesive 501 or AVM Primer 500				
9	For Aussie Membrane 502: Primed with Aussie Membrane 502 Part-A (Resin) or AVM Adhesive 501				
10	Aussie 500 detail coat (45 mils dry) at all inside and outside corners with Mat 800 Reinforcement - 6" min.				
11	Membrane dry film thickness per project design: 60 mils    90 mils    120 mils				
12	Mat 800 Reinforcement Fabric				
13	Penetrations detailed per AVM Detail -				
14	UV Exposure < 14 days				
15	AVM Drainboard installed over membrane				
16	Protection coarse over membrane				
17	Flood Testing				
18	Transition to pre-applied membrane per AVM detail-				

**COMMENTS:**

VERTICAL INSTALLATION		YES	NO	N/A	NOTES
<b>19</b>	Substrate free of dirt, debris, form release agents				
<b>20</b>	Voids or honeycombing filled with grout or Aussie Seal M				
<b>21</b>	Form-tie holes grouted				
<b>22</b>	Aussie Seal M fillet (3/4") at all inside corners				
<b>23</b>	For Aussie Membrane 500: Primed with AVM Adhesive 501 or AVM Primer 500				
<b>24</b>	For Aussie Membrane 502: Primed with Aussie Membrane 502 Part-A (Resin) or AVM Adhesive 501				
<b>25</b>	Aussie 500 detail coat (45 mils dry) at all inside and outside corners with Mat 800 Reinforcement - 6" min.				
<b>26</b>	Membrane dry film thickness per project design: 60 mils    90 mils    120 mils				
<b>27</b>	Penetrations detailed per AVM Detail -				
<b>28</b>	AVM Drainboard installed over membrane				
<b>29</b>	Protection coarse over membrane				
<b>30</b>	Termination at grade completed per project design				
<b>31</b>	Transition to pre-applied membrane per AVM detail-				
<b>32</b>	UV Exposure < 14 days				

**COMMENTS:**

VERTICAL INSTALLATION		YES	NO	N/A	NOTES
<b>ADDITIONAL ITEMS FOR AUSSIE MEMBRANE 502 SPRAY APPLICATION</b>					
<b>33</b>	Adhesion test completed				
<b>34</b>	Aussie 500 detail coat (45 mils dry) at all inside and outside corners with Mat 800 Reinforcement - 6" min.				
<b>35</b>	Membrane dry film thickness at 60 mils - Non-Hydrostatic conditions				
<b>36</b>	Membrane dry film thickness at 90 mils - Hydrostatic conditions				
<b>37</b>	Correct resin to salt water ratio				
<b>38</b>	Totes or drums have been fully mixed				
<b>*100% Inspections must be completed and documented for the following:</b>					
	Vertical and horizontal substrate				
	Post installation of all AVM Waterproofing products				
	Post installation of rebar				
	During placement of concrete				

**COMMENTS:**



# Aussie Membrane 500/502 Inspection Checklist

COMMENTS: