
AVM-0550G 0560G-0002

AVM System 550G/0560G

## Slab on Grade over Aussie Skin, Concrete Walls (500/502)





#### Notes:


DETAIL #:

AVM-0550G\_0560G-0004

AVM System 550G/560G

## Slab on Grade over Aussie Skin, Concrete Walls (Aussie Mate)





#### Notes:


DETAIL #:

AVM-0550G\_0560G-0006

AVM System 550G/560G

## Slab on Grade over Aussie Skin, Concrete Walls (520)





#### Notes


DETAIL #:

AVM-0550G\_0560G-0008

AVM System 550G/560G

# Slab on Grade over Aussie Skin, CMU (Block) Walls (500/502)





### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.


AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.avmindustri<u>es.com</u> DETAIL #:

AVM-0550G\_0560G-0010

AVM System 550G/560G

# Slab on Grade over Aussie Skin, CMU (Block) Walls (520)






#### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.avmindustries.com DETAIL #:
AVM-0550G\_560G-0012
AVM System 550G/560G

## Slab on Grade over Aussie Skin, Concrete Walls, Minimal Exposed Footing (500/502)





#### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.


AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.avmindustries.com DETAIL #:

AVM-0550G\_0560G-0014

AVM System 550G/560G

Slab on Grade over Aussie Skin, Concrete Walls, Minimal Exposed Footing (520)





#### Notes:


1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 roducts www.avmindustries.com

DETAIL #:
AVM-0550G\_0560G-0016
AVM System 550G/560G

## Elevated Slab over Aussie Skin, Concrete Walls (500/502)





### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304


FILE NAME: 0550G 0560G-0016

888.414.1041 818.888.0050 www.avmindustries.com

DETAIL #:
AVM-0550G\_0560G-0018
AVM System 550G/560G

## Elevated Slab over Aussie Skin, Concrete Walls (520)





#### Notes:


DETAIL #:

AVM-0550G\_0560G-0020

AVM System 550G/506G

## Elevated Slab over Aussie Skin, Concrete Walls Aussie Mate






### Notes:

DETAIL #:
AVM-0550G\_0560G-0022
AVM System 550G/560G

# Aussie Membrane 500/502 Installation over Aussie Skin.






### Notes:

DETAIL #: 0550G\_0560G-1200

AVM System 550G/560G

# Typical Lagging Wall Single System (Non-Hydrostatic)






#### Notes:

DETAIL #: 0550G\_0560G-1210

AVM System 550G/560G

# Blindside Waterproofing over Lagging Single System - Hydrostatic






#### Notes:

# Blindside Waterproofing over Lagging Single System with Insulation - Hydrostatic






### Notes:

## Lagging Wall with Rock Pocket






#### Notes:

DETAIL #: 0550G\_0560G-1224

AVM System 550G/560G

## Raised Slab Single System (Non-Hydrostatic)





#### Notes:


DETAIL #:

0550G\_0560G-1225

AVM System 550G/0560G

# Raised Slab - Shotcrete Retaining Wall Single System (Non-Hydrostatic)






#### Notes

# DETAIL #: 0550G\_0560G-1228

Raised Slab with Vapor Barrier



Aussie Skin 550G/560G




#### Notes:

DETAIL #: 0550G\_0560G-1229

Aussie Skin 550G/560G

## **Vapor Barrier Transition**






#### Notes:

DETAIL #: 0550G\_0560G-1230

AVM System 550G/560G

# Mat Slab Drainage System Single Layer System





### Notes:


DETAIL #:

0550G\_0560G-1240

AVM System 550G/560G

## Typical Lagging Wall Metal Sheet Pile with Plywood Single Layer System






#### Notes:

DETAIL #: 0550G\_0560G-1242

AVM System 550G/560G

Typical Lagging Wall Shotcrete Retaining Single Layer System






## Notes:

## Sheet Pile Retaining Wall

# INDUSTRIES INC

## Aussie Skin 550G/560G




## Notes:

Aussie Skin 550G/560G

## Metal Tie-Back Cover Single Layer System



## Only Use if AVM's Standard Tie-Back Cover Cannot be Used



### Notes:


- 1. Relief cuts may be needed to form Aussie Skin around tie-back cover. All relief cuts should be covered with Sanded Tape.
- 2. All nails, screws etc used to hang the Aussie Skin above the water table must be non-rusting and sealed with AVM approved Sealant.

DETAIL #: AVM-0550G\_0560G-1531

Aussie Skin 550G/560G

# Detensioned Tie-Back Box-out Single Layer System






### Notes:

# 4" Tie-Back Cover Single Layer System





## Notes:

0550G 0560G-1533


System

Aussie Skin 550G/560G

## 6" Tie-Back Cover



## Aussie Skin 550G/560G



### Notes:

0550G 0560G-1534


System

Aussie Skin 550G/560G

## 8" Tie-Back Cover



## Aussie Skin 550G/560G




### Notes:

DETAIL #: 0550G 0560G-1536

Aussie Skin 550G/560G

### Raker Beam Detail






### Notes:

DETAIL #: 0550G 0560G-1537

Aussie Skin 550G/560G

### Raker I-Beam Detail






## Notes:

DETAIL #: 0550G\_0560G-1540 AVM System 550G/560G

# Back Lagged Soldier Pile Single Layer System






#### NOTES:

## Mid-Lagged Soldier Pile with Insulation



## Aussie Skin 550G/560G




### NOTES:

DETAIL #: 0550G\_0560G-1544

AVM System 550G/560G

## Lagging Board Removal at Grade






#### NOTES

AVM-0550G\_0560G-2500

AVM System 550G/560G

## Aussie Skin Under Grade-Beam - Hydrostatic






### NOTES:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent  $adhesion\ between\ the\ membrane\ and\ wet\ Concrete\ or\ Shotcrete.\ Aussie\ Skin\ 560G\ is\ an\ approved\ methane/VOC\ barrier.$
- Concrete must cure min 7 days prior to Aussie 520 installation.
- Aussie Membrane 520 must cure 24 hours prior to concrete placement.

AVM-0550G\_0560G-2540 AVM System 550G/560G

## Aussie Skin Over Grade-Beam - Hydrostatic





#### NOTES:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. Concrete must cure min 7 days prior to Aussie 520 installation.
- 3. Aussie Membrane 520 must cure 24 hours prior to concrete placement.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304

Quality Waterproofing Products


888.414.1041 818.888.0050 www.avmindustries.com

AVM-0550G\_0560G-2550

AVM System 550G/560G

# Aussie Skin Over Grade-Beam Non-Hydrostatic





#### NOTES:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304

**Quality Waterproofing Products** 


888.414.1041 818.888.0050 www.avmindustries.com

DETAIL #: AVM-0550G 0560G-2610

AVM System 550G/560G

#### Pile Cap Detail - Hydrostatic





#### NOTES:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. Concrete Surface must be free of dirt, debris, release agents and anything else that might inhibit bonding.
- 3. Concrete surface must be structurally sound, uniform and finished with a light broom finish.
- 4. Aussie Membrane 520 must cure 24 hours prior to concrete placement.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304

**Quality Waterproofing Products** 


888.414.1041 818.888.0050 www.avmindustries.com DETAIL #:

AVM-0550G\_0560G-2630

AVM System 550G/560G

#### Pile Cap Detail - Non-Hydrostatic





#### Notes:


1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304

888.414.1041 818.888.0050 www.avmindustries.com Pipe Raker in Slab

Aussie Skin 550G/560G





#### Notes:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. Steel must be clean and rust free prior to applying Aussie Seal M.
- 3. Aussie Skin target sheet only necessary if field sheet is not cut tightly around pipe with gaps >1/4"


FILE NAME: 0550G 0560G-2800

AVM-550G\_0560G-2802

AVM System 550G/560G

#### Pipe Bank Pitch Pan





#### NOTES:


- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. Aussie Membrane 520 should be cured prior to concrete placement which may take up to 72 hours. Please consult AVM if scheduling does not allow this.

AVM-550G 0560G-2804

AVM System 550G/560G

#### Slab Penetration






#### Notes:

AVM-0550G\_0560G-2806

AVM System 550G/560G

## Foundation Slab Well Pipe Sealing Box-out






#### NOTES:

#### Slab Tie Penetration

# INDUSTRIES INC

#### Aussie Skin 550G/560G




#### Notes:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. Target sheet is required if gap between field sheet and rod is >2"

#### Aussie Skin Underslab Repair





#### NOTES:


AVM-550G\_560G-3000

Aussie Skin 550G/560G

#### Elevator Pit Over Aussie Skin



#### Aussie Skin 550G/560G



#### NOTES:


AVM-0550G\_0560G-4000

AVM System 550G/560G

## Through Wall Penetration Sealant on Sanded Side - Single System



#### Aussie Skin 550G/560G



#### NOTES:


AVM-0550G 0560G-4002

AVM System 550G/560G

## Multiple Pipe Penetration Sealant on Sanded Side - Single System



#### Aussie Skin 550G/560G



#### NOTES:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. PVC or metal pipe must be clean and free of foreign matter that would prevent Aussie Seal M adhesion.
- 3. 6" minimum spacing required between multiple pipes. Closer spacing may be allowed with specific limitations and required enhancements prior to job start in writing from AVM

0550G\_0560G-4003


Systen

Aussie Skin 550G/560G

#### Blindside Vertical Pitch Pan



#### Aussie Skin 550G/560G



#### Notes:

0550G\_0560G-4004


System

Aussie Skin 550G/560G

#### Vertical Pitch Pan - Post-Applied



#### Aussie Skin 550G/560G



#### Notes:


AVM-550G 0560G-4005

AVM System 550G/560G

## Sleeved Pipe Penetration Single System



#### Aussie Skin 550G/560G



#### Notes:


AVM-0550G 0560G-4010

AVM System 550G/560G

## Pipe Penetration Sealant on HDPE Side Single System



#### Aussie Skin 550G/560G




#### Notes:

#### Cored Penetration Sealant on HDPE Side

# INDUSTRIES INC

#### Aussie Skin 550G/560G



#### Notes:


DETAIL #: 0550G\_0560G-4100

AVM System 550G/560G

#### Rebar Tie Single Layer System



Aussie Skin 550G/560G




#### Notes:

#### Non-Flush Fastener Detail



#### Aussie Skin 550G/560G




#### Notes:

#### Nail/Screw Detail



#### Aussie Skin 550G/556G




#### Notes:

Aussie Skin 550G

#### Lapping Detail - Single Salvage Edge




#### **FACTORY LAP**



Important Note: When installing the "Factory Lap", The Installation procedure should be as follows:

- 1) Remove the black plastic film from the factory lap to expose the adhesive.
- 2) Lay down the 2nd layer of Skin over the exposed Adhesive. (leave 1/8"-1/4" of adhesive exposed) Roll the steel roller over the 2nd layer of skin several times while applying significant pressure.
- 3) Verify seam is completely and properly bonded.

#### **NON-FACTORY LAP**



Important Note: When installing the "Non-Factory Lap", The Installation procedure should be as follows:

- 1) Remove the black plastic film from one side of the double-sided tape.
- 2) Lay down the Double-Sided Tape on the sanded side of the first layer of Aussie Skin.
- 3) THOROUGHLY COMPRESS THE DOUBLE-SIDED TAPE ONTO THE SANDED SIDE OF THE AUSSIE SKIN USING AVM'S APPROVED STEEL
- ROLLERS. (ROLL THE STEEL ROLLER OVER THE TAPE SEVERAL TIMES WHILE APPLYING SIGNIFICANT PRESSURE!)
- 4) Carefully remove the clear film (2nd layer of film) from the Double-Sided Tape.
- 5) Lay down the 2nd layer of Skin over the exposed double-Sided Tape. (Leave 1/8"-1/4" of tape exposed) Roll the steel roller over the 2nd layer of skin several times while applying significant pressure.
- 6) Verify seam is completely and properly bonded.
- 7) If multiple pieces of Double-Sided Tape are needed, overlap them!

#### NOTES:

- 1. Aussie Skin 550G is a Heavy, Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membrane with added technologies creating excellent adhesion between the membrane and wet Concrete or Shot-Crete.
- 2. All surfaces must be clean and sound before installing the Lap Joints
- 3. Double sided tape must be used as supplied (min. 4" wide)
- 4. Below the water table, drain board may be substituted with approved protection layer

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304


FILE NAME: 0550G-6000

888.414.1041 818.888.0050 www.avmindustries.com

#### Lapping Detail - Dual Salvage Edge




#### FACTORY LAP - DUAL SALVAGE EDGE



Important Note: When installing the "Factory Lap", The Installation procedure should be as follows:

- 1) Remove the black plastic film from the factory lap on the bottom sheet to expose the adhesive.
- 2) Remove the black plastic film from the factory lap on the top sheet and lay down onto 1st layer of Skin over the exposed Adhesive. (leave 1/8"-1/4" of adhesive exposed) Roll the steel roller over the 2nd layer of skin several times while applying significant pressure.
- 3) Verify seam is completely and properly bonded.

#### NON-FACTORY LAP



Important Note: When installing the "Non-Factory Lap", The Installation procedure should be as follows:

- 1) Remove the black plastic film from one side of the double-sided tape.
- 2) Lay down the Double-Sided Tape on the sanded side of the first layer of Aussie Skin.
- 3) THOROUGHLY COMPRESS THE DOUBLE-SIDED TAPE ONTO THE SANDED SIDE OF THE AUSSIE SKIN USING AVM'S APPROVED STEEL
- ROLLERS. (ROLL THE STEEL ROLLER OVER THE TAPE SEVERAL TIMES WHILE APPLYING SIGNIFICANT PRESSURE!)
- 4) Carefully remove the clear film (2nd layer of film) from the Double-Sided Tape.
- 5) Lay down the 2nd layer of Skin over the exposed double-Sided Tape. (Leave 1/8"-1/4" of tape exposed) Roll the steel roller over the 2nd layer of skin several times while applying significant pressure.
- 6) Verify seam is completely and properly bonded.
- 7) If multiple pieces of Double-Sided Tape are needed, overlap them!

#### NOTES:

- 1. Aussie Skin 550G is a Heavy, Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membrane with added technologies creating excellent adhesion between the membrane and wet Concrete or Shot-Crete.
- 2. All surfaces must be clean and sound before installing the Lap Joints
- 3. Double sided tape must be used as supplied (min. 4" wide)


FILE NAME: 0550G-6002



Aussie Skin 550G

#### Non-Factory Lap with Detail Strip





Important Note: When installing the "Alternative Non-Factory Lap", The Installation procedure should be as follows:

- 1) Remove the black plastic film from the Detail Strip to expose the Adhesive.
- 2) Lay down the first layer of Aussie Skin over the exposed Adhesive covering half the width of the detail strip. Roll the steel roller over the seam several times while applying significant pressure.
- 3) Lay down the 2nd layer of Aussie Skin over the remaining exposed adhesive. Leave 1/8"-1/4" of adhesive exposed between the two sheets of Aussie Skin. Roll the steel roller over the seam several times while applying significant pressure.
- 4) Verify seam is complete and properly bonded.

#### NOTES:


- 1. Aussie Skin 550G is a Heavy, Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membrane with added technologies creating excellent adhesion between the membrane and wet Concrete or Shot-Crete.
- 2. All surfaces must be clean and sound before installing the Lap Joints

DETAIL #: 0550G\_0560G-6005 System 550G/560G

# Lapping Detail with Aussie Seal M and Sanded Tape

Aussie Skin 550G/560G





#### Notes:


- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. All surfaces must be clean and sound before installing the lap joints. (Remove excess sand before applying double sided tape)



T-Lap Detail




AVM System 550G\_560G



#### Notes:

#### Standard Overlap Spacing





#### Notes:


- 1. Aussie Skin 550G is a Heavy, Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membrane with added technologies creating excellent adhesion between the membrane and wet Concrete or Shot-Crete.
- 2. All surfaces must be clean and sound before installing the lap joints. (Remove excess sand before applying double sided tape)

DETAIL #: AVM-550G 560G-6020

AVM System 550G/560G


#### **Under Slab Assembly**





#### Notes:






#### Notes:



## Outside Corner Detail - at Bottom of Wall





#### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304

FILE NAME: 0550G\_0560G-6260


Quality Waterproofing Products

888.414.1041 818.888.0050

www.avmindustries.com

#### Transition to Aussie Mate 580-AL






#### Notes:

DETAIL #: 0550G\_0560G-7010

AVM System 550G/560G

## Aussie Skin Lagging Wall to Aussie Mate Free Standing Wall Transition






### **PLAN VIEW**

#### Notes:



## Aussie Skin Installation over Aussie Membrane 500/502/520.






#### Notes:

DETAIL #: 0550G\_0560G-7022 Aussie Skin 550G/560G

#### Aussie Skin Transition to Aussie Mate 580-AL Option 1

Aussie Skin 550G/560G






#### Notes

DETAIL #: 0550G\_560G-7024 Aussie Skin 550G/560G

#### Aussie Skin Transition to Aussie Mate 580-AL Option 2

Aussie Skin 550G/560G






#### Notes:

#### **Grade Termination - Option 1**






#### Notes:

#### Grade Termination - Option 2





#### Notes:

0550G\_0560G-8002


System


Aussie Skin 550G/560G

# Repair Procedure for Large Areas of Damage - Sanded Side


Aussie Skin 550G/560G







#### STEP 3



#### Notes:

- 1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.
- 2. This repair procedure is intended for large areas of damage (cutout areas, misplaced penetrations, etc.). Please refer to AVM Detail 0550G/0560G-8004 for repair procedures for small cuts and punctures.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.avmindustries.com

0550G/0560G - 8004

System

Aussie Skin 550G/560G


# Repair Procedure for Cuts, Slices, and Small Punctures

Aussie Skin 550G/560G


FACING INSTALLER




# CUT OR SLICE IN AUSSIE SKIN AUSSIE SKIN SUBSTRATE HORIZONTAL OR VERTICAL PREP AREA WITH A WIRE BRUSH TO REMOVE ANY LOOSE GRANULES GRANULAR SIDE



#### **PUNCTURES - NON-WATER TABLE**



#### PUNCTURES - WATER TABLE OR UNDER-SLAB



#### Notes:

1. Aussie Skin 550G and 560G are Heavy Duty, Easy to Install, Puncture Resistant Sheet Waterproofing Membranes with added technologies creating excellent adhesion between the membrane and wet Concrete or Shotcrete. Aussie Skin 560G is an approved methane/VOC barrier.

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304 888.414.1041 818.888.0050 www.avmindustries.com