

DETAIL #:
0580-AL-7002-M


Aussie Mate 580-AL Methane

Standard Overlap

**AVM AUSSIE MATE 580-AL
METHANE / VOC BARRIER ONLY**




FACTORY LAP



Important Note: When installing the "Factory Lap", The Installation procedure should be as follows:

1. Before bonding the next layer of Aussie Mate 580-AL to an existing layer, Remove both clear plastic films from the factory laps (Where the aluminum protection layer ends and the 2-1/2" release liner on the bitumen side of the 2nd sheet)
2. Make sure surfaces are clean before bonding overlaps.
4. Install the next sheet of Aussie Mate 580-AL with a minimum 2-1/2" overlap.
5. Roll the steel roller over the lap several times while applying pressure to ensure proper adhesion.
6. In cold weather, using heat gun will improve adhesion.

NON-FACTORY LAP



Important Note: When installing the "Non-Factory Lap", The Installation procedure should be as follows:

1. Make sure surfaces are clean before bonding overlaps.
2. Pull release liner back and tuck under previous sheet - Do not remove plastic liners
3. Install the next sheet of Aussie Mate 580-AL with a minimum 2-1/2" overlap.
4. Roll the steel roller over the lap several times while applying pressure to ensure proper adhesion.
5. In cold weather, using heat gun will improve adhesion.
6. In the water-table, on non-factory laps Apply Sealant (Aussie Seal M) over the seam.

NOTES:

1. Aussie Mate 580-AL is an LARR approved Waterproofing membrane and Methane Barrier.
2. Aussie Mate 580-AL is a UV stable, heavy duty bituminous sheet membrane with aluminum protection layer for Below-Grade waterproofing applications and is available in a 60 mil or 80 mil thickness.
3. Aussie Mate 580-AL may also be used as a methane and/or vapor barrier under horizontal slabs on grade.