



AVM® Aussie Coat 620-AL Slow Cure

Heavy Duty Aliphatic Balcony, Parking Deck, Plaza Deck & Mechanical Waterproofing

Generic Spec

Section 071800 / 071816 / 096700 / 096713

Product Name

AVM® Aussie Coat 620-AL Slow Cure

By

AVM Industries, Inc.
8245 Remmet Ave, Canoga Park, CA 91304
888.414.1041 818.888.0050
www.avmindustries.com

Product Description

AVM® Aussie Coat 620-AL Slow Cure is a two-component aliphatic, low to no odor, slow-setting, slow-curing, solvent-free*, high-performance, and high solids polyurea/urethane waterproof membrane system that can be applied suitably for heavy-duty wearing surface applications on prepared interior or exterior concrete, under asphalt overlays, plywood, and metal surfaces. Due to the slow gel time, AVM® Aussie Coat 620-AL Slow Cure is suitable for applications in temperatures as low as 20°F. It may be applied in a single thickness at 200 mils on one pass. AVM® Aussie Coat 620-AL Slow Cure is also relatively insensitive to moisture and temperature, allowing applications in various temperatures and humidity.

Where to Use

AVM® Aussie Coat 620-AL Slow Cure is intended for use as the Top Coat for Polyurethane Pedestrian and Vehicular Deck Coating Systems. It can also be applied to properly prepared interior or exterior concrete, plywood, and metal surfaces.

Warranty

Contact AVM Industries for warranty details

Delivery, Storage, and Handling

- Delivery of all the system materials to the job site must be in their original sealed containers and bags, with manufacturer's name and label intact.
- Handle and store containers and bags in accordance with printed instructions.
- Store at temperatures between 50°F and 90°F.
- Keep all materials out of the reach of children.
- If irritation occurs during use, liberally flush affected areas with water. If irritation continues, see a physician immediately

Installation

Surface Preparation:

Surface must be clean and dry. When installing over Aussie Membrane 520 (base coat), the base coat must be fully cured and tack free.

Mixing:

Premix Part A and Part B components using a low-speed mechanical mixer until a homogeneous mixture and color is obtained (typically 3 minutes). Use care not to allow the entrapment of air into the mixture.

Application:

Apply at the recommended coverage rate using a roller, notched squeegee, or trowel. When applying an aggregate coat, (sand layer) Apply the aggregate evenly at the appropriate rate into the wet coating and if desired, back-roll. (see AVM System 620 installation instructions). AVM® Aussie Coat 620-AL Slow Cure requires a continuous coating application to minimize lines and/ or streaking. For proper adhesion between coats, re-coating must be done within 8-12 hours.

Curing:

At 75°F (24°C) and 50% relative humidity, allow each coat to cure a minimum 30 minutes to 2 hours. Cure time will vary depending on temperature and humidity. If more than 24 hours passes between coats, reprime surface with AVM Primer 401 or Primer 420.

Allow a minimum 30 minutes to 2 hours before permitting light pedestrian traffic and at least 12 hours before heavy traffic. Cure time will vary depending on temperature and humidity.

Cleanup:

All cleanup should be done in accordance with local regulations

Limitations:

The following conditions must not be coated with AVM® Aussie Coat 620-AL Slow Cure: Split slabs, buried membrane, sandwich slabs with insulation, slabs over unvented metal pan, magnesite, and non-structural lightweight concrete.

Surfaces must be dry, clean, and free of foreign matter. Containers that have been opened must be used as soon as possible. Do not dilute with solvent.

Maintenance

Contact AVM for Details

Availability and Cost

Contact AVM Industries or your approved applicator for pricing and availability.

Technical Services

Technical services are available by contacting our offices at: 888.414.1041 or 818.888.0050 or visit www.avmindustries.com

System Specifications

See next page

AVM® Aussie Coat 620-AL Slow Cure Technical Information

Item	Packaging	Approx Shipping Weights	VOC
AVM® Aussie Coat 620-AL Slow Cure (Part A & B Combined)	5 Gal Kit	56 Lbs	60 g/l
Part-A (Net Contents 4 Gallon/15.4 Liters)	5 Gal Bucket	45 Lbs	60 g/l
Part-B (Net Contents 1 Gallon/1.54 Liters)	1 Gal Bucket	11 Lbs	60 g/l

Property	Results	Test Method
Specific Gravity	Side A: 1.05 ± 0.1 Side B: 0.99 ± 0.1	
Hardness	92 ± 3	ASTM D-2240 Shore A
Pot Life (min @ 75°F [24°C], 50% RH)	30 ± 45 minutes	
Tack Free Time	3-4 Hours	
Tensile Strength	2500 ± 100 pli (17.2 ± 0.7 kN/m)	ASTM D-412
Elongation	800 ± 100%	ASTM D-412
Tear	300 ± 25 pli (52.5 ± 4.4 kN/m)	ASTM D-624
Viscosity, at 75°F (24°C)	Side A: 1500-2500 cps Side B: 50-150 cps	
Total Solids by Volume	95%	ASTM D-2697
Volatile Organic Compounds	<0.49 lbs/gallon (59 gm/liter)	ASTM D-2369-81

Coverages

Item	Coverage Rate
AVM® Aussie Coat 620-AL Slow Cure @ 30 Mils	55 sqft/gal
AVM® Aussie Coat 620-AL Slow Cure @ 20 Mils	80 sqft/gal
AVM® Aussie Coat 620-AL Slow Cure @ 15 Mils	105 sqft/gal

Note: These are theoretical coverage rates and may vary depending on substrate types or if used as a topcoat over sand.

For a complete list of details in BIM (revit), CAD or PDF, please visit our website at www.avmindustries.com.

Approval(s): <https://www.avmindustries.com/approvals/>
Learn more about the detailed standards our products meet for approvals by various US or International Agencies or Code Councils

Patent(s): <https://www.avmindustries.com/patents/>
Some features of our product or assembly may be protected under one or more US or International Patent(s)

AVM Industries, Inc. 8245 Remmet Ave, Canoga Park, CA 91304
888.414.1041 818.888.0050
Quality Waterproofing Products
www.avmindustries.com

